



Hafa® Dine

Art: 1382020, 1382021, 1382022



Spare Parts



Hafa
Svarvaregatan 5, Box 525
SE-301 80 Halmstad
SWEDEN

Garanti/Warranty.
Service, resevdelar/spare-parts
Sweden: Tel: +46 (0)35 15 44 75
Norway: Tel: +47 69 31 02 30
Finland: Puh: 0207 43 50 00

www.hafa.se
www.hafa.dk
www.hafabad.no
www.hafa.se
www.hafabathroom.ru
www.hafa.eu

E-mail:
service@hafa.se
service@hafabad.no

	art.no.	beskrivning	description
1	9209821	INSATS KÖKSBLANDARE	CARTRIDGE KITCHEN MIXER
2	9209822	ENGREPPSHANDTAG KÖKSBLANDARE KROM	HANDLE KITCHEN MIXER CHROME
	9209823	ENGREPPSHANDTAG KÖKSBLANDARE SVART	HANDLE KITCHEN MIXER BLACK
	9209824	ENGREPPSHANDTAG KÖKSBLANDARE MÄSSING	HANDLE KITCHEN MIXER BRASS
3	9209825	OMSTÄLLARVRED KÖKSBLANDARE KROM	DIVERTER HANDLE KITCHEN MIXER CHROME
	9209826	OMSTÄLLARVRED KÖKSBLANDARE SVART	DIVERTER HANDLE KITCHEN MIXER BLACK
	9209827	OMSTÄLLARVRED KÖKSBLANDARE MÄSSING	DIVERTER HANDLE KITCHEN MIXER BRASS
4	9316-C	FÄSTMUTTER STOR SVART	FIXATION NUT BIG BLACK
5	9316-B	DEKORRING KÖKSBLANDARE KROM	DECOR RING CHROME
	9209833	DEKORRING KÖKSBLANDARE SVART	DECOR RING BLACK
	9209834	DEKORRING KÖKSBLANDARE MÄSSING	DECOR RING BRASS
6	9209835	INSATS DISKMASKINSAVSTÄNGNING	CARTRIDGE DISHWASHER
7	9316-H	MUTTER FÖR INSATS 35MM	THIN NUT FOR CARTRIDGE SINGLE LEVER MIXER
8	9600240	SLANG SVART KROM KÖKSBLANDARE DINE	SWING ARM DINE CHROME
	9600241	SLANG SVART MÄSSING KÖKSBLANDARE DINE	SWING ARM DINE BLACK
9	9308-C	FLEXSLANG ANSLUTNING BLANDARE PAR	FLEXIBLE HOSE FOR MIXERS WATER INLET PAIR
10	9209840	MUNSTYCKE KÖKSBLANDARE KROM	NOZZLE FOR MIXER CHROM
	9209841	MUNSTYCKE KÖKSBLANDARE SVART	NOZZLE FOR MIXER BLACK
	9600242	MUNSTYCKE KÖKSBLANDARE MÄSSING	NOZZLE FOR MIXER BRASS
11	9600049	INSEXSKRUV MED TÄCKBRICKA KROM	ALLEN SCREW WITH COVER CHROME
	9600031	INSEXSKRUV MED TÄCKBRICKA SVART	ALLEN SCREW WITH COVER BLACK