Hafa® SERVE XL & PEAK XL

Art: 1382530, 1382531, 1382532, 1382533, 1382534, 1382560, 1382561, 1382562, 1382563, 1382564



Hafa®
Hafa
Svarvaregatan 5, Box 525
SE-301 80 Halmstad
SWEDEN

Garanti / Warranty.
Service, reservdelar / spare parts
Sweden: +46 (0)35 15 44 75
Norway: +47 (0)69 31 02 30
Finland: +358 (0)20 743 57 40

www.hafa.se
www.hafa.dk
www.hafabad.no
www.hafa.se

e-mail:
info@hafa.se
info@hafabad.dk
info@hafabad.no
info@hafa.fi

Art: 1382530, 1382531, 1382532, 1382533, 1382534, 1382560, 1382561, 1382562, 1382563, 1382564

No.	ART. NO.	BESKRIVNING	DESCRIPTION
1	-	BLANDARKROPP, EJ TILLGÄNGLIG SOM RESERVDEL	MIXER BODY, NOT AVAILABLE AS SPARE PART
2	-	BLANDARPIP, EJ TILLGÄNGLIG SOM RESERVDEL	MIXER SPOUT, NOT AVAILABLE AS SPARE PART
3	9600483	MUNSTYCKE KÖKSBLANDARE PULL-OUT BLANK ROSTFRI	NOZZLE KITCHEN MIXER PULL-OUT POLISHED STAINLESS
	9600484	MUNSTYCKE KÖKSBLANDARE PULL-OUT MATT SVART	NOZZLE KITCHEN MIXER PULL-OUT MATTE BLACK
	9600485	MUNSTYCKE KÖKSBLANDARE PULL-OUT BORSTAD MÄSSING	NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRASS
	9600486	MUNSTYCKE KÖKSBLANDARE PULL-OUT BORSTAD BRONS	NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	9600487	MUNSTYCKE KÖKSBLANDARE PULL-OUT BORSTAD ROSTFRI	NOZZLE KITCHEN MIXER PULL-OUT BRUSHED STAINLESS
4	9600468	BACKVENTIL Ø15x16 DN15 KÖKSBLANDARE PULL-OUT	CHECK VALVE FOR KITCHEN MIXER PULL-OUT
5	9600370	INSATS MINGDI 35MM	CARTRIDGE MINGDI 35MM
6	9600449	DEKORRING KÖKSBLANDARE BLANK ROSTFRI	DECOR RING KITCHEN MIXER POLISHED STAINLESS
	9600450	DEKORRING KÖKSBLANDARE MATT SVART	DECOR RING KITCHEN MIXER MATTE BLACK
	9600451	DEKORRING KÖKSBLANDARE BORSTAD MÄSSING	DECOR RING KITCHEN MIXER BRUSHED BRASS
	9600452	DEKORRING KÖKSBLANDARE BORSTAD BRONS	DECOR RING KITCHEN MIXER BRUSHED
	9600453	DEKORRING KÖKSBLANDARE BORSTAD ROSTFRI	DECOR RING KITCHEN MIXER BRUSHED STAINLESS
7		ENGREPPSHANDTAG KÖKSBLANDARE XL BLANK ROSTFRI	HANDLE KITCHEN MIXER XL POLISHED STAINLESS
		ENGREPPSHANDTAG KÖKSBLANDARE XL MATT SVART	HANDLE KITCHEN MIXER XL MATTE BLACK
		ENGREPPSHANDTAG KÖKSBLANDARE XL BORSTAD MÄSSING	HANDLE KITCHEN MIXER XL BRUSHED BRASS
		ENGREPPSHANDTAG KÖKSBLANDARE XL BORSTAD BRONS	HANDLE KITCHEN MIXER XL BRUSHED BRONZE
		ENGREPPSHANDTAG KÖKSBLANDARE XL BORSTAD ROSTFRI	HANDLE KITCHEN MIXER XL BRUSHED STAINLESS
8	9600461	INSEXSKRUV M5x3 MED TÄCKBRICKA GRÅ KÖKSBLANDARE	ALLEN SCREW M5x3 WITH COVER FOR KITCHEN MIXER GREY
9	9600470	BOTTENRING KÖKSBLANDARE XL BLANK ROSTFRI	BASE RING KITCHEN MIXER XL POLISHED STAINLESS
	9600471	BOTTENRING KÖKSBLANDARE XL MATT SVART	BASE RING KITCHEN MIXER XL MATTE BLACK
	9600472	BOTTENRING KÖKSBLANDARE XL BORSTAD MÄSSING	BASE RING KITCHEN MIXER XL BRUSHED BRASS
	9600473	BOTTENRING KÖKSBLANDARE XL BORSTAD BRONS	BASE RING KITCHEN MIXER XL BRUSHED BRONZE
	9600474	BOTTENRING KÖKSBLANDARE XL BORSTAD ROSTFRI	BASE RING KITCHEN MIXER PULL-OUT BRUSHED STAINLESS

Hafa
Svarvaregatan 5, Box 525
SE-301 80 Halmstad
SWEDEN

Garanti / Warranty.
Service, reservdelar / spare parts
Sweden: +46 (0)35 15 44 75
Norway: +47 (0)69 31 02 30
Finland: +358 (0)20 743 57 40

www.hafa.se
www.hafa.dk
www.hafabad.no
www.hafa.se

e-mail:
info@hafa.se
info@hafabad.dk
info@hafabad.no
info@hafa.fi

Art: 1382530, 1382531, 1382532, 1382533, 1382534, 1382560, 1382561, 1382562, 1382563, 1382564

No.	ART. NO.	BESKRIVNING	DESCRIPTION
10	9600459	FIXERINGSGÄNGA M34 BLANDARE	THREADED FIXATION PART M34 FOR MIXERS
11	9600458	FIXERINGSMUTTER M34 BLANDARE	FIXATION NUT M34 FOR MIXERS
12	9600394	FLEXSLANG ANSLUTNING BLANDARE 500MM G3/8 PAR	FLEXIBLE HOSE FOR MIXER WATER INLET 500MM G3/8 2 PCS
13	9600456	INSEXSKRUV M5x5 MED TÄCKBRICKA GRÅ KÖKS-BLANDARE 2ST	ALLEN SCREW M5x5 WITH COVER FOR KIT-CHEN MIXER GREY 2PCS
14	9600477	OMSTÄLLARVRED KÖKSBLANDARE XL BLANK ROSTFRI	DIVERTER HANDLE KITCHEN MIXER PULL-OUT POLISHED STAINLESS
	9600478	OMSTÄLLARVRED KÖKSBLANDARE XL MATT SVART	DIVERTER HANDLE KITCHEN MIXER PULL-OUT MATTE BLACK
	9600479	OMSTÄLLARVRED KÖKSBLANDARE XL BORSTAD MÄSSING	DIVERTER HANDLE KITCHEN MIXER PULL-OUT BRUSHED BRASS
	9600480	OMSTÄLLARVRED KÖKSBLANDARE XL BORSTAD BRONS	DIVERTER HANDLE KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	9600481	OMSTÄLLARVRED KÖKSBLANDARE XL BORSTAD ROSTFRI	DIVERTER HANDLE KITCHEN MIXER PULL OUT BRUSHED STAINLESS
15	9600455	INSATS DISKMASKINSAVSTÄNGNING KÖKSBLAN-DARE	CARTRIDGE DISHWASHER FUCTION KITCHEN MIXER
16	9600460	FLEXSLANG ANSLUTNING DISKM. KÖKSBLANDARE 500MM G1/2	FLEXIBLE HOSE FOR DW CONNECTION KIT-CHEN MIXER 500MM G1/2
17	9600489	SLANG KÖKSBLANDARE PULL-OUT	HOSE KITCHEN MIXER PULL-OUT
18	9600469	SLANG KÖKSBLANDARE PULL-OUT KORT 230MM	HOSE KITCHEN MIXER PULL-OUT SHORT 230MM
19	9600547	KOPPLING SVART SLANG TILL KÖKSBLANDARE PULL-OUT	CONNECTOR BLACK FOR PULL-OUT HOSE KITCHEN MIXER
20	9600666	MOTVIKT KÖKSBLANDARE PULL-OUT	COUNTERWEIGHT KITCHEN MIXER PULL-OUT
21	9600667	HYLSA FÖR SLANG KÖKSBLANDARE PULL-OUT	HOSE PROTECTION KITCHEN MIXER PULL OUT

Hafa
Svarvaregatan 5, Box 525
SE-301 80 Halmstad
SWEDEN

Garanti / Warranty.
Service, reservdelar / spare parts
Sweden: +46 (0)35 15 44 75
Norway: +47 (0)69 31 02 30
Finland: +358 (0)20 743 57 40

www.hafa.se
www.hafa.dk
www.hafabad.no
www.hafa.se

e-mail:
info@hafa.se
info@hafabad.dk
info@hafabad.no
info@hafa.fi